User's manual for art. 3003
Manuale d'uso per art. 3003

This page is intentionally left blank

La Easy Control è un piccolo registratore DMX che può essere di grande utilità per piccole installazioni, quando l'uso di una centralina DMX implica una spesa troppo costosa e quindi non conveniente.

Il vantaggio che si trae dall'utilizzo della Easy Control non è soltanto economico: il nostro DMX recorder è infatti così semplice da usare, da essere adatto anche ai meno esperti.

Quando usare la Easy Control?
Quando, per esempio, si vogliono installare dei fari, far loro eseguire dei programmi personalizzati e l'acquisto di una centralina DMX rappresenta una spesa troppo dispendiosa. In tal caso è infatti possibile preparare fino ad un massimo di 7 programmi differenti usando una centralina DMX standard. Quando i programmi sono pronti, si possono scaricare sulle Easy Control, che potrà allora eseguirli.

Ovviamente **non è possibile cambiare i programmi dalla Easy Control**, mentre è possibile operare con le seguenti funzioni:
• Scegliere uno fra i sette programmi
• Cambiare la velocità della sequenza del programma
• Eseguire il programma in manuale o automaticamente
• Fermare il programma
• Memorizzare fino ad un massimo di sette differenti programmi ed un massimo di 127 passi per ogni programma
• Utilizzare fino ad un massimo di 512 canali DMX
• Tutti i programmi vengono memorizzati in una memoria flash di 4 Mb

Connessione ed uso della Easy Control

Connettere un controller (Control Show, Control Spot, Mini Control, Fancy) ai fari con il cavo DMX standard. Preparare le varie scene come al solito con l' unica accortezza di non utilizzare il fading che supera immediatamente le capacità della Easy Control. Dopo aver preparato le scene da registare, connettere direttamente il controller alla Easy Control. Far partire il controller facendogli eseguire in "automatico" le scene preparate, quindi procedere con la registrazione.

REGISTRAZIONE:
1) Scegliere il programma 1-7 con il pulsante **PROGRAM**
2) Tenere premuto il pulsante **RECORD** e premere il pulsante **PLAY**
3) Per fermare la registrazione premere **STOP**

ESECUZIONE AUTOMATICA:
1) Scegliere il programma 1-7 premendo il pulsante **PROGRAM**
2) Premere il pulsante PLAY
3) E' possibile cambiare la velocità tramite il pulsante **SPEED + /-**

ESECUZIONE MANUALE:
1) Premere il tasto **STOP**
2) Scegliere il programma 1-7 premendo il pulsante **PROGRAM**
3) Scegliere lo step tramite il pulsante **STEP + /-**

FORMATTAZIONE:
1) Togliere tensione
2) Premere il tasto **STOP** e **PROGRAM**
3) Ridare tensione alla centralina continuando a tenere premuti i pulsanti

⚠ IMPORTANTE

Non registrare con il fading perchè il numero di step necessario supera immediatamente la capacità della centralina

... page 2
...

The Easy Control is a small DMX recorder that can solve many problems in small installations, when the price of a DMX controller is too high and therefore not acceptable.

The advantage in using the Easy Control is not only in the price, but also in the easiness of use: our DMX recorder is in facts very easy to operate and thus suitable for everybody.

What is the concept of Easy Control?
Having to install, for instance, 2 or 3 Giants, it is evident that the use of a DMX controller is too expensive. In such a case, it is possible to prepare up to a maximum of 7 different programmes by using any standard DMX controller. Once the programmes are ready, they can be downloaded in the Easy Control, which is now ready to run them.

Obviously, **it is not possible to change the programmes from the Easy Control**, while on the other hand it is possible to operate with the following functions:
• Choose 1 among the 7 different programmes
• Change the speed of the sequence of the programme
• Run the programme normally or automatically
• Stop the programme
• Storage up to a maximum of 7 different programmes up to a maximum of 127 cues for each programme
• It accepts up to a maximum of 512 DMX channels
• The programmes are stored in a 4 mb flash memory

Connection and use of the Easy Control

Connect one controller (Control Show, Control Spot, Mini Control, Fancy) to the fixtures with a DMX standard cable. Arrange the scenes as usual but do not use the fading as the number of steps needed immediately exceeds the capacity of the controller. Once you have prepared the scenes you can connect the controller to the Easy Control directly. You can start the controller in “auto mode” and start to record with the Easy Control.

... page 3 ...

RECORDING:

1) Connect your DMX-controller to Easy Control (record in- connector)
2) Choose the program 1…7 through PROGRAM key (for ex. Program n°1)
3) Keep the REC key pressed and then press the PLAY key: after 1 sec, the record led lights up and start the recording.
4) Change the cues on your DMX-controller (manually or automatically). The Easy Control record the cues and the times (for ex. First cue.. 10 sec… second cue.. 5 sec…. Third cue)
5) Press the STOP key to stop the recording
6) Disconnect your DMX-controller
7) Switch off he Easy Control

PLAY

1) Connect the Spots to Easy Control (Play-out connector)
2) Switch on the easy Control. Automatically you have the first cue, after 10 sec you have the second cue, after 5 sec. You have the third cue etc. (Program n°1)
3) Now, if you keep pressed the speed key you change the times. If you keep pressed the + key the
   times decrease (for ex. . First cue.. 5 sec… second cue.. 2.5 sec…. Third cue). The Easy Control record the new times.
   Now if you switch off and then switch on the Easy Control you have: .
   First cue.. 5 sec… second cue.. 2.5 sec…. Third cue

INITIALIZATION:

1) Switch off the controller
2) Press the **STOP** and **PROGRAM** buttons
3) Switch on the controller by keeping the buttons pressed

⚠ WARNING

Do not record with fading on because the number of steps needed immediately exceeds the capacity of the controller.

This page is intentionally left blank

Head Office: STUDIO DUE Light Division s.r.l.

Str. Poggino, 100 - 01100 Viterbo (Italy)
tel. +39/761/353902 • +39/761/352520
fax +39/761/352653

Asia branch: STUDIO DUE Far East LTD

Unit D 29/F West Gate Tower
7 Wing Hong Street Kln. Hong Kong
tel. +852/29542141
fax +852/23302515

Rev • 1-12/99

The features on this brochure are not binding: they can be changed without notice.
Le caratteristiche riportate su questo catalogo non sono impegnative e possono essere soggette a variazioni senza preavviso.